

#594 Small Miner Fountain

Items Required For Assembly

170 GPH Pump (not provided)

- 1) Place bowl (A) on a firm, level surface.
- 2) Place the pump into the pumphouse cavity at the rear of the bowl (A). Drape the electrical cord from the pump over the rear rim of the bowl where the groove is located.
- 3) Place the rock falls fountain top (B) onto the rear portion of the bowl (A), fitting it inside the raised rim.
- 4) Gently tilt up the rock fall fountain top (B) enough to allow you to attach the 1/2" vinyl tubing that protrudes from the bottom of the rock falls top onto the outlet of the pump. Gently lower the rock falls fountain top back onto the bowl. Make sure that the tubing is not kinked as this will restrict water flow. You may cut the vinyl tubing as necessary.
- 5) Fill the bowl (A) with clean water so that the pump is completely submerged.
- 6) Place the miner figurine (C) in place on the rock falls fountain top (B).
- 7) Plug the pump into a GFCI protected outlet and enjoy your new fountain.

